## **AXLE SERVICE TOOLS**

## **FRUEHAUF "PRO-PAR" LOCK-NUT WRENCH**



## WHEEL BEARING LOCK-NUT WRENCHES

	Part No.	Opening Size
	ZE1597A	4-13/16" (8 pt.)
	ZE1909	3-1/4" (8 pt.)
	ZE1914	4" (6 pt )
HOW TO DETERMINE THE WRENCH	ZE1918	4-7/8" (6 pt.)
SIZE YOU NEED	ZE1925	3-3/4" (8 pt.)
Using a caliper or other suitable measuring device, determine the size of the Lock-Nut. Consult the chart at right to select the Lock-Nut wrench of corresponding size.	ZE1935	3-1/8" (8 pt.)

## **AXLE SPINDLE SERVICE TOOL**

